

# BV9500

- [lineage install](#)
- [lineage-19.0-20211106-UNOFFICIAL-treble\\_arm64\\_bvS.img.xz](#)

apply these settings from developer menu:

- OEM unlock
- debug usb

adb commands

```
adb devices # confirm on screen
adb reboot bootloader
fastboot flashing unlock
# press volume up to confirm
```

flash system

```
fastboot flash system lineage-19.0-20211106-UNOFFICIAL-treble_arm64_bvS.img
```

From:

<https://wiki.csgalileo.org/> - **Galileo Labs**

Permanent link:

<https://wiki.csgalileo.org/tips/android/bv9500?rev=1638606941>

Last update: **2021/12/04 09:35**

