

# PCB with CNC

- [reference](#)
- fritzing
- online [jscut guide](#)
- online [ncviewer](#)
- online [drill to gcode converter](#)
- TODO online [carbide3d](#)


CNC for PCB:

- 22000RPM
- V-Bit cutter 30 degree 0.2mm
- first pass 0.04mm
- second pass 0.07mm with more feed

## fritzing


Make electronic schema with fritzing

[autoroute.webm](http://autoroute.webm)




Make pcb routing:

- routing → DRC settings → 32mil large
- routing → DRC (check design at the end)




export gerber files



# flatcam

setup flatcam



### Cutout Tool Options

**Parameters:**

Tool Diameter: 2,000

Cut Z: -2,000

Multi-Depth: 0,2000

Kind:  Single  Panel

Margin: 0,1000

Gap size: 4,0000

Plot Area Tools Database

ID	Tool Name
1	v-tool 60 0.1

**Tool Description**

Name: v-tool 60 0.1

Diameter: 0,1924

Diameter Tolerance: 0,0000

Min: 0,0000

Max: 0,0000

Operations: General

**Isolation Parameters**

Passes: 2

Overlap: 45,0000 %

Milling Type:  Climb  Conventional

Follow:

Isolation Type:  Full  Ext  Int

**Paint Parameters**

Overlap: 20,000 %

Offset: 0,0000

Method: Standard

Connect  Contour

**NCC Parameters**

Operation:  Clear  Isolation

Milling Type:  Climb  Conventional

**Drilling Parameters**

Cut Z: -2,0000

Offset Z: 0,0000

MultiDepth:

DPP: 0,2000

Travel Z: 2,0000

Feedrate Z: 50,0000

Feedrate Rapids: 500,0000

Spindle speed: 5000

Dwell:

Dwelltime: 0,0000

Drill slots:

Overlap: 0,0000 %

Last drill:

**Milling Parameters**

Shape: V

V-Dia: 0,1000

V-Angle: 60,0000

Tool Type: Rough

Tool Offset: Path

Custom Offset: 0,0000

Cut Z: -0,0000

MultiDepth:

DPP: 0,0000

Travel Z: 1,0000

ExtraCut:

E-Cut Length: 0,1000

Feedrate X-Y: 60,0000

Feedrate Z: 60,0000

FR Rapids: 500,0000

Spindle Speed: 6000,0000

Dwell:

Dwelltime: 1,0000

calcolato

[openfiles.webm](#)

[mirror.webm](#)

[bottom.webm](#)

[top.webm](#)

[drill.webm](#)

# deprecated

## convert gerber to svg

Upload <name>\_copperBottom.gbl to <https://tracespace.io>, select layers, download zip and extract <name>\_copperBottom.gbl



Now with inkscape we need to process the complex SVG with multiples path, objects, layers, group, etc. to convert it into a single path simple SVG. You need to open your SVG into Inkscape (Open-Source, cross-platform), and perform the following series of commands:

- CTRL+A (Select all),
- CTRL+U (Ungroup),
- CTRL+ALT+C (Convert stroke to path),
- CTRL+A (Select all),
- CTRL+U (Union) and
- CTRL+SHIFT+R (Fit page to content).
- CTRL+S save

## svg to gcode

Open [jscut](#):

- load SVG <name>\_copperBottom.gbl
- make all mm (link)
- zero lower left (link)
- select all objets, drills and path
- create operation
  - outside, 0.1mm
- generate
- save gcode

edit gcode to set spindle speed to 8000 rpm and turn on it clockwise (after G90)

```
; after first G1  
M3 S5000
```

## carbide3d

set spindle speed to 8000 rpm and turn on it clockwise (after G90)

```
G00 Z1.000  
M3 S10000
```

substitute G01 F400 with G01 F40

substitute G00 Z3.000 with G00 Z1.000

deprecated

- export your PCB as .svg files by clicking on “Export for PCB” on the bottom. Click on the small arrow on the Export button and select “Etchable (SVG)”. You will get a bunch of svg's exported in your selected directory but we will only use two of them:
  - yourfilename\*\_etch\_copper\_bottom\_mirror.svg
  - yourfilename\*\_etch\_mask\_bottom\_mirror.svg

From:

<https://wiki.csgalileo.org/> - **Galileo Labs**

Permanent link:

<https://wiki.csgalileo.org/tips/pcb?rev=1620629602>

Last update: **2021/05/10 08:53**

