

BV7000 PRO

Upgrade firmware

- download SP flash tool for linux (latest release) from <https://spflashtool.com/>
- download firmware from <http://bbs.blackview.hk/viewtopic.php?f=176&t=191529> and unzip
- install libpng12 from [deb](#)

untar flash tool and

```
chmod +x flash_tool*
```

run

```
sudo ./flash_tool.sh
```

- go to “download section”, select scatter file inside “R*” firmware folder, uncheck “userdata” and press download.
- connect powered down PHONE to USB (yes phone POWERED OFF !!!)
- after green check on screen unplug phone and power on

From:

<https://wiki.csgalileo.org/> - Galileo Labs

Permanent link:

<https://wiki.csgalileo.org/tips/android/bv7000>

Last update: **2017/07/24 09:29**

