

BV9500

```
(
*
[[https://community.e.foundation/t/device-support-project-treble/19645|supported devices]]
*
[[https://www.getdroidtips.com/lineage-os-17-1-blackview-bv9500-plus-android-10/|lineage install]]
*
[[https://sourceforge.net/projects/andyyan-gsi/files/lineage-19.x/|lineage-19.0-20211106-UNOFFICIAL-treble_arm64_bvS.img.xz]]
```

apply these settings from developer menu:

- OEM unlock
- debug usb

adb commands

```
adb devices # confirm on screen
adb reboot bootloader
fastboot flashing unlock
# press volume up to confirm
```

flash system

```
fastboot flash system lineage-19.0-20211106-UNOFFICIAL-treble_arm64_bvS.img
fastboot flash system lineage-17.1-20210808-UNOFFICIAL-treble_arm64_bvS.img
fastboot reboot
```

From:

<https://wiki.csgalileo.org/> - **Galileo Labs**

Permanent link:

<https://wiki.csgalileo.org/tips/android/bv9500?rev=1638618300>

Last update: **2021/12/04 12:45**

