

Linux

Base

edit /etc/locale.gen and run locale-gen

```
apt-get install wiringpi python-pip  
  
# test GPIO  
gpio readall
```

non fare con raspbian recenti

```
# apt install rpi-update  
# rpi-update
```

camera

```
pip install "picamera[array]"
```

```
raspistill -tl 100 [-t 99999]
```

- picamera
- opencv 3.2
- opencv and raspberry

view picamera as normal USB camera

add to /etc/modules

```
echo bcm2835-v4l2 >> /etc/modules-load.d/modules.conf
```

control panel to change camera settings

```
sudo apt install v4l2ucp
```

From:
<https://wiki.csgalileo.org/> - **Galileo Labs**

Permanent link:
<https://wiki.csgalileo.org/tips/raspberry/linux>

Last update: **2017/05/03 12:05**



